

Sidemount Spare Tire Fender Modification

My understanding of the proper placement of the cutout template onto the driver's side rear fender based on what I can see in the photos provided in the original link:

TOP:	9 inches from the inside edge of the fender to the top vertical centerline of the template.
BOTTOM:	9 5/8 inches from the inside edge of the fender to the bottom vertical centerline of the template <u>AND</u> 3 inches up from the top of the body line of the fender to the bottom vertical center line of the template.
LEFT (inside):	5 3/4 inches from the inside edge of the fender to the left horizontal centerline of the template.
RIGHT (outside):	Looks like about 4(?) inches from the outside edge of the fender to the right horizontal centerline of the template.